

VI.5.3D-PQPFTIME PROGRAM FCST HCL TECHNIQUE PQPFTIME

Purpose

Technique PQPFTIME sets if Function ESP is to run using NWSRFS internal time and not in local standard time.

This Technique should only be used in conjunction with input time series that have also been saved on NWSRFS internal clock time time-steps and should not be used with historical data files.

Valid values are NO (0) and YES (1).

The Global default value is NO (0).

This Technique is Universal.

Form of Input

PQPFTIME(integer)

Example

PQPFTIME(1)

Function ESP will run using internal time.